



OPERATING MANUAL

FOR

LF-855D

**Multi-Function
SMD Rework System**

INTRODUCTION

Thank you for choosing XYTRONIC LF-855D Multi-Function S.M.D. Rework Station. This unit is the best tool for repairing work, combination with XYTRONIC LF-3000 and LF-852D which is specially designed for lead free soldering/desoldering, surface mount devices with temperature controlled hot air. The “2 in 1” design ,save your working space. Please read the operating manual carefully to maximize the advantages of using your new LF-855D multi-function SMD rework station and keep this manual readily accessible for future reference.



【WARNING 】 and 【CAUTION】



【ELECTRICAL SHOCK 】

Warning and Caution are positioned at critical points in the manual to draw the user’s attention to significant safety concerns. Be sure to comply with the following warnings and cautions for your safety.

This appliance is not intended for use by children or other persons without assistance or supervision if their physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure that they do not play with appliance. Failure to observe the safety regulation will result in a risk of life and limb. The manufacturer shall not be liable for damage resulting from misuse of the unit or unauthorized alterations.

1. **Please unscrew the 4 screws under the bottom enclosure when the unit is used at the first time. (See the procedure on page13)**
2. Ensure the voltage rating of the unit and your power supply are identical prior to use.
3. Check carefully of any damage during transportation.
4. Put the product on a safe and stable working table. Table surface should be consisted of fire and heat resistant material due to the unit can reach very high temperature and potentially dangerous.
5. During the operation, the heater is extremely hot, and will cause serious burns if contacted exposed skin. Use gloves and/or any heat resistant tools to pick up the PCB assembly to eliminate the possibility of burns.
6. Do not use the product near combustible gases or flammable materials.
7. Turn the power switch OFF and allow the heater to cool before checking or replacing heater and other parts, or prior to storing the unit.
8. Keep the appliance clean. This may be used with a damp cloth using small

amount of liquid detergent. Never submerge the unit in liquid or allow any liquid to enter the station. Never use any solvent to clean the case.

9. This unit is designed for soldering/desoldering, hot air SMD rework and should not be used for any other purpose without first consulting the manufacturer or its authorized agent.
10. Keep the unit out of the reach of children. Young children should be supervised to ensure that they do not play with the appliance.

To prevent electrical shock, be sure to take the following precautions:

1. Make sure the unit is grounded. Always connect power to a grounded receptacle.
2. Do not pressure the AC power cord. Be sure the work area is well ventilated.
3. Do not bump, hit, pour water/liquids or otherwise subject the heating surface to physical shock. This may damage the heater.
4. To isolate the equipment from the mains before commencing repairs or making any maintenance to avoid electric shock. This may result in Death or serious injury.
5. Do not expose the unit to moisture nor use the unit with wet hands.
6. Turn the power switch off and remove the AC power cord by pulling the plug (not the cable) when the unit will remain unused for a longer period of time.
7. Do not modify the unit.



Warning

Soldering / Desoldering Function Warning

- ◆ Always place the soldering & desoldering irons in its original holder when not being used.
- ◆ Keep the soldering and desoldering tip and heating element away from the body, clothes and flammable material when in operation.
- ◆ The soldering and desoldering tip and the heating element are still remaining hot after being switched off. Ensure that you do not touch the tips and the heating elements.
- ◆ For your health, do not inhale solder fumes.
- ◆ You must not undertake work on live parts. Only the technician is permitted to undertake repairs. Use the original replacement part only.

Hot Air Function Warning

- **To last the life of the heating element, not recommend continuously using at low air flow and high temperature.** Let the heating element be cooler after using a maximum 20 minutes. Ensure that it is placed back on its cooling stand to cool down between rework operations. Also, do not switch the hand tool on while it is in the cooling stand. **Fail to comply with the instructions may result in damage to the hand tool.**
- **Do not aim the hot air at your eyes.** Do not allow the hot air from the hand tool to aim the eyes as serious eye damage may occur.

- **The hot air pencil can produce a lot of heat.** Do not allow the heater and the nozzle to contact exposed skin as burning may occur. To eliminate the possibility of burns, allow time for the equipment to cool before commencing maintenance.
- **Death or serious injury may result from electric shock.** It is therefore essential to isolate the equipment from the mains before commencing repairs.
- **Keep the hot air away from the body, clothes and flammable material when in operation.** The nozzle metal is in a high temperature status, do not touch the nozzle! Always replace the hand tool to its original holder when not being use. The nozzle and the heating element are still remaining hot after being switched off. Ensure that you do not touch them.
- **Do not block the air outlet in full area of the nozzle, or it may cause the heat reflection and damage the heating element.**
- **Do not leave when the machine is on operating:** Stare at the nozzle when the rework station is on operating, so as not to burn your body or other objects. Turn off the machine and unplug the power cord when you are leaving and put the hot air handle to the holder in one side of the machine. The nozzle is still remaining hot after being switch off on some time. Ensure that you do not touch the nozzle.
- **Do not use if damaged:** If the pump doesn't work or the rework station becomes faulty, discontinue using immediately. To comply with safety standards, the pump or other part must only be replaced by authorized technicians as special purpose tools are required. Only the technician is permitted undertake repairs. Use the original replacement part only.
- **Remember unplug in the power cord:** The station must be switched off and the power cord must be unplug-in before replacing the fuse in AC socket in rear side of the machine.
- Do not unplug the power cord; when the power switch is turned off, the cooling system will begin to work automatically, the temperature falls down to 100°C (212 °F) to protect the heater, remember that do not unplug the power cord at this time until the unit stop working.

PRODUCT FEATURES

- ◆ “2 in 1” by design, saving working space, owning three function, can greatly meet the users need.
- ◆ With special intelligent chip microcomputer control design, double LED display operating by pressing keys, make it convenient and comfortable operation.
- ◆ Selection free for Fahrenheit and Centigrade (Celsius) temperature.
- ◆ “Password selection”: Temperature or air blow by digital display readout, easy to read. The temperature can be locked by “password” code that is convenient for production line management.

Soldering / Desoldering Function

- ◆ **HEATER/SENSOR FAILED DETECTION:** If sensor circuit failed that the display reads “S--E” and cut off the heater power. If heater circuit failed the display will read “H--E” and cut off the heater power.
- ◆ **TEMPERATURE “LOCK-OUT” FEATURE:** The temperature can be locked by “password” code that is convenient for production line management.
- ◆ **ESD SAFE AND SPIKE FREE CIRCUITRY:** The “Zero Voltage” electronic switching design also protects voltage and current sensitive components (CMOS devices, etc.) against damaging current and transient voltage spikes commonly produced by less efficient, mechanically switched stations.
- ◆ **LIGHTWEIGHT SOLDERING IRON:** Ergonomic mini handle that stays cool and prevents operator fatigue.
- ◆ **ENERGY SAVER MODE:** If the station has been idle for 20 minutes, the energy saver feature will automatically engage, the temperature goes down to 150°C from the set temperature for Soldering and 200°C from the set temperature for de-soldering. Activating the solder/desolder wands will disengage the power saving feature and the unit will immediately ramp up to the preset temperature. When over 40 minutes without operation the main power will be switched off to “sleep mode” which cuts power consumption and extends tip life.
Please note: You have to turn off the power switch first and then switch “ON” again to commence work when the unit goes to “Sleep” mode.
- ◆ **IRON WORKING OPTION:** When the users don't use the soldering or desoldering function, or they also set by pressing keys “SET + ▲”, at this time, the iron which you set will enter the power off suspend status. It means that the heater power is cut off. If press “▼” then the heater power will be on.


Hot Air Function

- ◆ With the high power heating element, heat up quickly, the momentary power can reach 600W.
- ◆ Temperature adjustable, suits for removing QFP, SOP, PLCC or SOJ chips etc., especially the built in static free circuit design is safety for the sensitive elements like CMOS ICs.
- ◆ **SENSOR /PUMP FAILED DETECTION:** If sensor circuit failed that the display read “S--E” and cut off the heater power. If the pump circuit failed that the display read “P-E” and cut off the heater power.
Auto-cooling design: When the power switch off, the cooling system will begin to work automatically, the temperature falls down to 100°C (212°F) to protect the heating element from burning ..
- ◆ **Heating element auto-protecting function:** When heating element reaching a high temperature which can be protected automatically, to lasting the life of heating element.

SPECIFICATIONS

Model		LF-855D Multi-function SMD REWORK STATION	
Power Voltage		220-240Vac 50Hz	100-120Vac 60Hz
Fuse(Fast Type)		5A (fast type)	10 A (fast type)
Power Consumption (Max)		700W	
Weight		7.5kg	
Solder	Power Consumption	90W	
	Temperature Range	100°C-520°C (212°F-896°F)	
	Sleeping Temperature	100°C (212°F)	
	Temperature correction range	+99°C~-99°C/+178°F~-178°F	
	Default setting	100°C	
		F-1: “000”	
		F-2 : “00”	
		F-3:“100”	
		F-4 : “°C”	
Hot Air	Power Consumption	600W	
	Air Flow	1.5 L / Min -40L / Min	
	Temperature range	100°C-480°C / 212°F-896°F	
	Air Flow	00-99	
	Default seting	F-1 : “000”	
		F-2 “°C”	
		Temperature 100°C Air Flow 00	

BRIEF INTRODUCTION OF PANEL FUNCTIONS:



Front panel

- ① Main power switch ② SIA socket ③ HOT-AIR Hole

Soldering Function Part

- ④ “▲”: Temperature increasing (UP)
 ⑤ “▼”: Temperature decreasing (Down)
 ⑥ Temp Display ⑦ Heat indicating light ⑧ “SET”: Function key

Hot Air Function Part

- ⑨ “▲”: Temperature increasing (UP)
 ⑩ “▼”: Temperature decreasing(Down)
 ⑪ Temp Display ⑫ Heat indicating light ⑬ “▲”: Hot air blow (UP)
 ⑮ Temp Display ⑯ “▼”: Hot air blow (DOWN)

Soldering /desoldering function introduction

TEMPERATURE SETTING: (No password set)

- ### PARAMETER SETTING:

- For example: $F-0 \rightarrow F-1 \rightarrow F-2 \rightarrow F-3 \rightarrow F-4$

- When the LED displays “F-1” and flashes, press “SET” key one time and the unit enters the Password Set status. At this moment, the LED displays the pre-set value. Press “▲” or “▼” key to change password set value. If the user sets “000” that means the unit will be under the status of no password. If the user sets “100” then means the unit will be under the password status. Press “SET” key once to finish password setting and the unit will backup mode, the user can continue set other modes or back from the setting mode.

- Press “SET” key once when the LED displays “F-2” and flashes that the unit enters the Temperature Correction Mode. At this moment, the LED displays preset correction value.

- Press “▲” or “▼” key to change the temperature correction value. The first digit “—” means minus (actual temperature is down), “No display” means plus (actual temperature is up).

- Press “▲” or “▼” key to change the temperature correction value. The first digit “—” means minus (actual temperature is down), “No display” means plus. Press

“SET” key once to finish the temperature correction and the unit automatically backup mode. The user may continue set other modes or back from the current setting mode.

Example for temperature correction: The current set temperature value is 300°C, however, the actual temperature is only 290°C. So it needs to correct by +10°C. Correction method: if the current correction value is 00 or -00; then change it to 10. If the current correction value is -20, then change it to -10. If the current correction value is 20, then change it to 30.

5. Sleep Mode Set:

Press “SET” key one time when the LED displays “F-3” and flashes, the unit enters the Sleep mode status. At this moment, the LED displays the pre-set value. Press “▲” or “▼” key to change the set value. If set value reads “000” that means the unit set in “Sleep” mode releasing status. If the display read “100” that means the unit set in “Sleep” mode. Press “SET” key once to finish the sleep mode setting, then the unit automatically backup. The user may continue set other modes or back from current set mode.

- **Please note the manufacturer original design will keep in “Free” status without setting “Sleep” mode.**

6. Wake-up method:

- ① Temperature Down Suspend: If the unit is set at Sleep mode function, after 20min idleness, the system will enter the sleep mode automatically, the temperature of soldering will go down to 150°C (302°F) / and the LED displays at “150” and flashes, the temperature of desoldering will go down to 200°C (392°F) and the LED displays at “200” and flashes. Activating the solder wand will disengage the suspend status and the unit will immediately ramp up to the preset temperature. There are three methods to wake-up the Temperature Down Suspend.
 - a. Soldering: Pick up the solder wand HF-90 and shake it gently.
 - b. Press any key of the unit.
 - c. Turn off the main switch and restart.
- ② Power off Suspend: If the unit enters the Sleep mode over 40min without wake-up, the unit will enter automatically the power off suspend status. It means the heater power will be cut off and the LED displays “— — —” and flashes. You can wake it up by pressing “▼” key when you reuse the iron or turn off the main switch and re-switch on.

7. Fahrenheit and Centigrade (Celsius) temperature selection

When temperature display window shows "F-4" and blinking, press the "SET" button, at this time, the system enters the degrees Fahrenheit and Centigrade temperature selection function, indicating the temperature of the window shows the current status. Press "▲" or "▼" key to change the temperature selection status. It expressed as degrees Celsius temperature value if set to “°C” ; it shows as degrees Fahrenheit temperature if set to °F

WORKING TEMPERATURE

SOLDERING

To meet RoHS requirements, the common 60/40 lead solder alloys are not allowed in the production process. Lead free solder alloys require a working temperature of 30°C (54°F) higher than previous generation electrical soldering. The working temperature of solder is detailed below and can vary from manufacture to manufacture.

Melting point	220°C (428°F)
Normal operation	300-360°C (572-680°F)
Production line operation	360-410°C (680-770°F)

When the soldering iron's working temperature is set within the parameters suitable for the type of soldering being used, a good joint assured. Too low of a temperature will slow the rate of solder flow while a high temperature setting might burn the flux in the solder and emit a heavy, white smoke resulting in a dry joint or permanent damage to the printed circuit board (P.C.B) and may also shorten tip life.

IMPORTANT: The temperature above 410°C (770°F) is not recommended for normal soldering functions, but can be used for short periods of time when high temperatures are required.

Hot air function introduction

TEMPERATURE SETTING: (No password set)

1. Increase temperature: By pressing “▲” key one time, the digital will be increase “1” numeral. If pressing “▲” key over 2 seconds then the digital numerals will be forwarded counting continuously till the temperature up to what you desire to set.
2. Decrease temperature: By pressing “▼” key, the same procedure as above.


AIR FLOW SETTING: (No password set)

1. Increase temperature: By pressing “▲” key one time, the digital will be increase “5” numeral. If pressing “▲” key over 2 seconds then the digital numerals will be forwarded counting continuously till the temperature up to what you desire to set.
2. Decrease temperature: By pressing “▼” key, the same procedure as above.

PARAMETER SETTING:

1. Press “SET” key and hold for at least 3 seconds until display shows “— — —” sign then release the “SET” key. The sign “— — —” starts to flash and reminding the user to input the mode lock password “010” (fixed). If the user inputs the same number as “010”, the unit will enter the modes selection procedure, otherwise, the unit will be back from the current mode automatically.
2. After the unit enters the Modes selection, the LED will display “F-0” and flash. Press “▲” or “▼” key to select modes. If the user doesn't press “▲” or “▼” key within 15 seconds or press “SET” key one time, then the unit will be immediately back from the Parameter Set status.

For example: F-0 → F-1 → F-2



3. Password Setting:

When the LED displays “F-1” and flashes, press “SET” key one time and the unit enters the Password Set status. At this moment, the LED displays the pre-set value. Press “▲” or “▼” key to change password set value. If the user sets “000” that means the unit will be under the status of no password. If the user sets “100” then means the unit will be under the password status. Press “SET” key once to finish password setting and the unit will backup mode, the user can continue set other modes or back from the setting mode.

4. Fahrenheit and Centigrade (Celsius) temperature selection

When temperature display window shows "F-4" and blinking, press the "SET" button, at this time, the system enters the degrees Fahrenheit and Centigrade temperature selection function, indicating the temperature of the window shows the current status. Press "▲" or "▼" key to change the temperature selection status. It expressed as degrees Celsius temperature value if set to °C; it shows as degrees Fahrenheit temperature if set to °F.

OPERATING INSTRUCTIONS

NOTE: In order to protect the pump during transportation, the pump in the machine is tightened by the 4 screws under the bottom enclosure. Please unscrew the 4 screws when the machine is used at the first time. (See Fig. A).




Fig. A

1. Ensure that the working voltage matches your power supply before beginning use.
2. Check carefully for any damage during transportation.
3. This unit contains:
 - A: HF-90 Soldering iron assembly with tip..
 - B: AC Power cord with plug.
 - C: Hot air gun
 - E: Accessories included:
 - a. cleaning brushes
 - b. 4pcs nozzles
 - c. iron holders
 - d. Hot air gun holder

OPERATING PROCEDURES

Caution: Check carefully for any damage during transportation and ensure that the working voltage matches your power supply before plugging in the station.

1. Ensure that the base unit's power switch is in the 'OFF' position.
2. Plug in "Solder" wands. Put the hot air gun to the (holder)
3. Connect AC power cord to mains "In-Let".
4. Turn switch "POWER SWITCH" to "ON" position and the switch led will be light.
5. All of the functions (Soldering and Hot air gun)will work at the same time after turning the power switch , and then the corresponding temperature LED or wind LED display will be ON and show the value.
6. Users can turn off the the Soldering function by pressing the key"SET+UP" ,then the corresponding LED display will show " _ _ _ ".
 NOTE: It means that the corresponding heater power is cut off.At this time ,the users can only use the hot air function.
 Pressing on the "▲" on can reuse the corresponding function.

A: Soldering function / Desoldering function option

- 1) Press the "▲" key up until the temperature to 250°C (482°F) (If set to degrees Centigrade, the temperature display window of the upper right corner shows °C, if set to degrees Fahrenheit, the temperature display window of the upper right corner shows °F).
- 2) Then tin the surface of soldering tips by applying a new covering of solder to protect it.
- 3) You can set the desired temperature setting by pushing the "up" or "down" key.
 When the temperature reaches to the desired temperature that the heating indicator

light will be flashed on and off to maintain the set temperature. The unit now is ready for use.

CAUTION: Do not touch any of the irons at any time while the unit is on or while it's cooling as they will still be hot.

COMMON CAUSES FOR TIP UNWETTING

1. Tip temperatures higher than 410°C (770°F).
2. The tip working surfaces are not tinned while the iron idling.
3. Lack of flux in soldering, wicking, repair, and touch-up operations.
4. Wiping the tip on a high sulfur content, dirty or dry sponge.
5. Contact with organic substances such as plastic, resin, silicone, grease and other chemicals.
6. Impurities in the solder and/or low tin content.

CARE OF TIPS

CAUTION: The soldering irons can reach very high temperature. Be sure to turn the unit off prior to carrying out any maintenance or trouble shooting steps listed below!

IMPORATNT:

Remove the tip and clean after each moderate to heavy use or daily for light usage. Remove any loose build up in the tip retaining assembly to prevent tip freezing.

Solder tips supplied are iron clad copper and if used properly should maintain optimum life.

1. Always tin the tip before returning it to the holder, turning off the station, or storing it for long periods of time. Wipe the tip on a brass cleaner prior to use.
2. Keeping the iron set at high temperatures (more than 400°C or 752°F) will shorten tip life.
3. Do not use excessive pressure on the tip or rub the joint with the tip while soldering and it does not improve the heat transfer and may damage the tip.
4. Apply solder to the joint, not the tip when soldering. The flux is naturally caustic and thus will eat away the tip.
5. Never clean the tip with a file or abrasive materials.
6. Do not use fluxes which contain chloride or acid. Use only rosin or resin activated fluxes.
7. If an oxide film forms, it can be removed by careful buffing with 600-800 grit emery cloth, isopropyl alcohol or equivalent and then the tinned areas with rosin-core solder after the resin-core has melted.

NEW TIPS

Applying the following steps give the tip optimum life.

1. Set both temperatures to min. then turn the main power switch to the “ON” position.
2. Set soldering tip temperature to 250°C (500°F approx.) and desoldering tip temperature to min. Coat the tinned surfaces with rosin-core solder after reaching 250°C.
3. Set to the desired temperature about 3 minutes after being warmed that the station will be ready for use once it reaches preset temperature.

IMPORTANT:

Remove and clean the tip daily. If a new tip is installed, remove any loose build up in the barrel assembly, otherwise the tip may fuse to the heating element or retaining barrel.

1. collector tube.
2. Depress vacuum switch, clean the tip tube with spring wire provided if there is no suction per the “Procedure for Cleaning Clogged Tip” section below.

B: Hot air function option

OPERATING PRECAUTIONS

1. Make sure both heater and nozzle are cool before attaching the nozzle.
2. Caution High Temperature Operation
Both nozzle and hot air are extremely hot and can cause burns. Never touch the nozzle and heater assembly or allow the hot air to blow against your skin. Initially, the iron may emit white smoke, but this will soon dissipate.

Operation Setup

1. Select the Nozzle that matches the size of the IC. Attach the nozzle when both heating element and the nozzle are cool and the unit is turned off and unplugged.
2. Loosen the screw on the nozzle and attach nozzle.
3. Press “▲” or “▼” key on the hot air function panel to choose the desired temperature or air flow.
4. Press “▲” or “▼” key to choose the desired air flow on the right side of the front panel. The speed will change 5 degrees by pressing the keys “▲” or “▼” at a time.
5. After adjusting the air flow and temperature and wait for the temperature to stabilize for a short period of time.

IMPORTANT: Do not force the nozzle or pull on the edge of the nozzle with pliers. Also, do not tighten the set-screw too tightly.

Suitable for desoldering of SMD components such as SOIC, CHIP, QFP, PLCC, BGA etc.

QFP De-soldering

1. **Melt the solder:** Hold the iron so that the nozzle is located directly over, but not touching the IC and allow the hot air to melt the solder. Be careful not to touch the leads of the IC with the nozzle.
2. **Remove the IC:** Once the solder has melted, remove the IC by lifting the pliers.
3. **Turn the power switch off:** After the power switch is off, an automatic blowing function begins sending cool air through the pipe in order to cool both the heating element and the handle. So do not disconnect the plug during this cooling process.
4. In case you don't use the unit for a long time, disconnect the plug.
Note: After the power switch off about one minute later, the temperature will fall down to 75°C (167°F) and power automatically shut off.
5. **Remove any remaining solder:** After removing the IC, cleaning the remaining solder chips with a wick or desoldering tool.
Note: For SOP, PLCC etc. would recommend by using tweezers iron to desolder.

QFP Soldering

1. **Apply the solder paste:** Apply the proper quantity of solder paste and flux (preferably no-clean) and place install the SMD on the PCB.
2. **Preheat SMD.**
3. **Soldering:** Heat the lead frame evenly.
4. **Washing:** When soldering is completed, wash the area with a defluxer.
Note: While there are many advantages of hot air SMD rework, it is also possible to have defects for soldering BGA. Will recommend to inspect all soldering joints closely.

PROCEDURE FOR REPLACING HOT AIR GUN HEATING ELEMENT



Caution : The main switch must be “off” and allow the iron to cool before attempting the following procedure

1. Unscrew the 3 screws on handle then take out the handle cover. (See Fig.1 below)
2. Disconnect the grounding wire jack and pull the heating element out from the stainless steel tube.

Important: Do not damage or loss the quartz glass and /or insulation mica inside of the stainless steel tube.

(See Fig.2 below)

1. Pull the default heater off and replace a new one then re-assembly the heater according the backward procedure.

(See Fig.3)




Fig.1




Fig.2




Fig.3

SPARE PART

Part No. 79-460012 Heating element 120Vac,60Hz,600W

Part No.79-560012 Heating element 230-240Vac,50Hz,600W

INTERCHANGEABLE ACCESSORY

1.INTERCHANGEABLE TIPS


Soldering tips for SIA : HF-90



I



B



1C



2C



3C




k



1.6D



4C



4.2D

2.INTERCHANGEABLE NOZZLES

					QFP	SOP	PLCC	SOJ	BGA(CSP)
					mm (inch)				
A1125B QFP 10 x 10 (0.39 x 0.39)	A1126B QFP 14 x 14 (0.55 x 0.55)	A1127B QFP 17.5 x 17.5 (0.68 x 0.68)	A1128B QFP 14 x 20 (0.55 x 0.78)	A1129B QFP 28 x 28 (1.1 x 1.1)					
10 (0.39) A:10.2 (0.4) B:10.2 (0.4)	15 (0.59) A:15.2 (0.6) B:15.2 (0.6)	19 (0.75) A:19.2 (0.76) B:19.2 (0.76)	21 (0.83) A:15.2 (0.6) B:21.2 (0.83)	29 (1.14) A:29.7 (1.17) B:29.7 (1.17)					
A1135B PLCC 17.5 x 17.5 (0.68 x 0.68) (44 針)	A1136B PLCC 20 x 20 (0.78 x 0.78) (52 針)	A1137B PLCC 25 x 25 (0.98 x 0.98) (68 針)	A1138B PLCC 30 x 30 (1.18 x 1.18) (84 針)	A1139B PLCC 12.5 x 7.3 (0.49 x 0.29) (18 針)					
15 (0.59) A:18.5 (0.73) B:18.5 (0.73)	19 (0.75) A:21 (0.83) B:21 (0.83)	24 (0.94) A:26 (1.02) B:26 (1.02)	29 (1.14) A:31 (1.22) B:31 (1.22)	6.9 (0.27) A: 9 (0.35) B:14 (0.55)					
A1140B PLCC 11.5 x 11.5 (0.45 x 0.45) (28 針)	A1141B PLCC 11.5 x 14 (0.45 x 0.55) (32 針)	A1182B BQFP 24 x 24 (0.94 x 0.94)	A1187B TSOL 18.5 x 8 (0.73 x 0.31)	A1257B SOP 11 x 21 (0.43 x 0.83)					
10 (0.39) A:13 (0.51) B:13 (0.51)	10 (0.39) A:15 (0.59) B:13 (0.51)	21 (0.83) A:24.2 (0.95) B:24.2 (0.95)	18.5 (0.73) A:20.2 (0.8) B:20.2 (0.8)	11.7 (0.46) A:12.2 (0.48) B:12.2 (0.48)					
A1258B SOP 7.6 x 12.7 (0.3 x 0.5)	A1259B SOP 13 x 28 (0.51 x 1.1)	A1260B SOP 8.6 x 18 (0.34 x 0.71)	A1261B QFP 20 x 20 (0.78 x 0.78)	A1262B QFP 12 x 12 (0.47 x 0.47)					
11.7 (0.46) 8.2 (0.32)	29 (1.14) 13.5 (0.53)	19 (0.75) 8.7 (0.34)	21 (0.83) A:20.2 (0.8) B:20.2 (0.8)	12 (0.47) A:12.2 (0.48) B:12.2 (0.48)					
A1263B QFP 28 x 40 (1.1 x 1.57)	A1264B QFP 40 x 40 (1.57 x 1.57)	A1265B QFP 32 x 32 (1.26 x 1.26)							
29 (1.14) A:27.7 (1.09) B:39.7 (1.56)	39 (1.54) A:40.2 (1.58) B:40.2 (1.58)	31 (1.22) A:32.2 (1.27) B:32.2 (1.27)							
A1124B 單管式 Ø2.5 (0.09)	A1130 單管式 Ø4.4 (0.17)	A1131 SOP 4.4 x 10 (0.17 x 0.39)	A1132 SOP 5.6 x 13 (0.22 x 0.51)	A1133 SOP 7.5 x 15 (0.3 x 0.59)					
Ø2.5 (I.D.) (0.09)	Ø4.4 (I.D.) (0.17)	4.8(0.19)	5.7(0.22)	7.2(0.29)					
A1134 SOP 7.5 x 18 (0.3 x 0.7)	A1142B Bent Single 1.5 x 3 (0.06 x 0.12)	A1170	A1110						
19 (0.75) 7.2(0.28)	1.5 (0.06) 45° 0.12 (0.012) (I.D.)	Ø7 (I.D.)	Ø10 (I.D.)						